

## Table of Contents

<b>D. Pneumatic and Fluid Modules</b> .....	<b>D-2</b>
<b>AN5—Air Module</b> .....	<b>D-2</b>
<b>1. Product Overview</b> .....	<b>D-2</b>
<b>2. Installation</b> .....	<b>D-3</b>
<b>2.1 Module Installation</b> .....	<b>D-3</b>
<b>2.2 Module Removal</b> .....	<b>D-4</b>
<b>3. Operation</b> .....	<b>D-5</b>
<b>4. Maintenance</b> .....	<b>D-5</b>
<b>5. Troubleshooting and Service Procedures</b> .....	<b>D-6</b>
<b>5.1 Troubleshooting</b> .....	<b>D-6</b>
<b>5.2 Service Procedures</b> .....	<b>D-7</b>
5.2.1 Master Side Self-Sealing Valve .....	<b>D-7</b>
5.2.2 Tool Side Self-Sealing Valve .....	<b>D-9</b>
5.2.3 Rubber Bushing Replacement .....	<b>D-11</b>
<b>6. Recommended Spare Parts</b> .....	<b>D-12</b>
<b>7. Specifications</b> .....	<b>D-13</b>
<b>8. Drawings</b> .....	<b>D-14</b>

## D. Pneumatic and Fluid Modules

### AN5—Air Module

#### 1. Product Overview


Air modules provide air utility and are attached to the Master and Tool plates. When the Tool Changer is coupled, the Master module passes the air supply to the Tool module for use by the customer tooling. Significant forces are encountered when using these modules. Assistance from the robot may be required to overcome these forces when coupling the Tool Changer.

**NOTICE:** The Master and Tool modules contain self-sealing valves. Do not use self-sealing valves for vacuum utility.

The Master and Tool modules contain pass-through ports and self-sealing valves. Pass-through ports release the air or vacuum when the Tool Changer is uncoupled. Before uncoupling the Tool Changer, turn off the air pressure or vacuum supply for the pass-through ports. Unlike pass-through ports, self-sealing valves prevent the air circuits from discharging, which eliminates the need to close those circuits upstream.

Table 1.1—Air Modules		
Module	Customer Connections	Ports/Valves
AN5 Master and Tool Modules	(6) G 3/8 (BSPP) (S1, S2, S3, S4, S5, & S6)	(6) self-sealing check
	(4) G 1/2 (BSPP) (P1, P2, P3, & P4)	(4) pass-through ports

Figure 1.1—Modules



Depending on the model, the Master and Tool modules contain pass-through ports and self-sealing valves. Pass-through ports release the air or vacuum when the Tool Changer is uncoupled. Before uncoupling the Tool Changer, turn off the air pressure or vacuum supply for the pass-through ports. Unlike pass-through ports, self-sealing valves prevent the air circuits from discharging, which eliminates the need to close those circuits upstream.

## 2. Installation

The air modules are typically installed by ATI prior to shipment. The following steps outline the installation or removal.



**WARNING:** Do not perform maintenance or repair(s) on the Tool Changer or modules unless the Tool is safely supported or placed in the tool stand, all energized circuits (e.g. electrical, air, water, etc.) are turned off, pressurized connections are purged and power is discharged from circuits in accordance with the customer's safety practices and policies. Injury or equipment damage can occur with the Tool not placed and energized circuits on. Place the Tool in the tool stand, turn off and discharge all energized circuits, purge all pressurized connections, and verify all circuits are de-energized before performing maintenance or repair(s) on the Tool Changer or modules.



**WARNING:** All pneumatic fittings and tubing must be capable of withstanding the repetitive motions of the application without failing. The routing of electrical and pneumatic lines must minimize the possibility of over stressing, pullout, or kinking the lines. Failure to do so can cause critical electrical and/or pneumatic lines to malfunction and might result in injury to personnel or damage to equipment.



**CAUTION:** Thread locker applied to fasteners must not be used more than once. Fasteners might become loose and cause equipment damage. Always apply new thread locker when reusing fasteners.

### 2.1 Module Installation


Refer to [Figure 2.1](#)

**Tools required:** 5 mm Allen wrench (hex key), torque wrench

**Supplies required:** Clean rag, Loctite® 242

1. Place the Tool in a secure location.
2. Uncouple the Master and Tool plates.
3. Turn off and de-energize all energized circuits (e.g. electrical, air, water, etc.).
4. Clean the mounting surface on the Tool Changer or Utility Coupler.
5. Place the module into the appropriate location on the Tool Changer or Utility Coupler body. Align the module with the Tool Changer using the dowels in the bottom of the ledge feature.
6. Apply Loctite 242 to the supplied M6 socket head cap screws. Using a 5 mm Allen wrench, install the (2) M6 socket head cap screws securing the module to the Tool Changer or Utility Coupler and tighten to 89 in-lbs (10.0 Nm).
7. Connect air plumbing to the module. Ensure that the connectors are clean.
8. After the procedure is complete, resume normal operation.

**Figure 2.1—Master Module Installation**



## 2.2 Module Removal

**Tools required:** 5 mm Allen wrench

**Supplies required:** Clean rag

1. Place the Tool in a secure location.
2. Uncouple the Master and Tool plates.
3. Turn off and de-energize all energized circuits (e.g. electrical, air, water, etc.).

**NOTICE:** Debris can be expelled at high velocity during the purge, take all required safety precautions.

4. All customer plumbing connections to the module must be purged.
  - a. Verify that the supply lines are turned off.
  - b. Cover the valves with a rag for safety.
  - c. Manually actuate the self-sealing valves to purge the line pressure.
5. Use a marker pen to indicate where the module is to be re-installed.
6. Disconnect air plumbing to the module.
7. Remove the (2) M6 socket head cap screws using a 5 mm Allen wrench
8. Remove the module from the Tool Changer or Utility Coupler.

### 3. Operation

Air modules pass air utilities from the Master to the Tool for use by the customer’s tooling. Unlike pass-through ports, self-sealing valves prevent the air circuits from discharging, which eliminates the need to close upstream circuits. Self-sealing valves and pass-through ports operate at a maximum pressure of 100 psi (6.9 bar).

**NOTICE:** If the air pressure is not released from the Tool side of the pass-through port, debris can be expelled at high velocity when the Tool Changer uncouples. Take all required safety precautions.

### 4. Maintenance

Perform maintenance to maximize the operational life of the module.

 **WARNING:** Do not perform maintenance or repair(s) on the Tool Changer or modules unless the Tool is safely supported or placed in the tool stand, all energized circuits (e.g. electrical, air, water, etc.) are turned off, pressurized connections are purged and power is discharged from circuits in accordance with the customer’s safety practices and policies. Injury or equipment damage can occur with the Tool not placed and energized circuits on. Place the Tool in the tool stand, turn off and discharge all energized circuits, purge all pressurized connections, and verify all circuits are de-energized before performing maintenance or repair(s) on the Tool Changer or modules.

A preventive maintenance schedule and checklist are provided in the following table:

<b>Table 4.1—Preventive Maintenance Schedule</b>	
<b>Inspection Schedule</b>	<b>Action Required</b>
Weekly	Clean and inspect
6 months or 500,000 cycles	Seal replacement
<b>Weekly Maintenance:</b>	
<ul style="list-style-type: none"> <li><input type="checkbox"/> Clean the mating surfaces. Use a vacuum to remove any debris and clean in and around the mating surfaces of the modules using a nylon brush (ATI Part Number 3690-0000064-60). Lubricate seals periodically with Magnalube G lubricant.</li> <li><input type="checkbox"/> Inspect modules for air leaks. Replace components as necessary.</li> </ul>	
<b>6 Months or 500,000 Cycle Maintenance:</b>	
<ul style="list-style-type: none"> <li><input type="checkbox"/> On modules with self-sealing ports, remove and replace self-sealing valve O-rings and seals in the both the Master and Tool Module. During O-ring and seal replacement inspect components (valve stem, check valve piston, and spring) of the valve assemblies in the Master and Tool modules. Refer to <a href="#">Section 5.2.1—Master Side Self-Sealing Valve</a> and <a href="#">Section 5.2.2—Tool Side Self-Sealing Valve</a>.</li> <li><input type="checkbox"/> Inspect pass-through air port rubber bushings. Refer to <a href="#">Section 5.2.3—Rubber Bushing Replacement</a>.</li> <li><input type="checkbox"/> Check that module mounting bolts are secure. Refer to <a href="#">Section 2.1—Module Installation</a>.</li> </ul>	

## 5. Troubleshooting and Service Procedures

This troubleshooting section provides information to help diagnose conditions with the Tool Changer or air module as well as service procedures for component replacement.



**WARNING:** Do not perform maintenance or repair(s) on the Tool Changer or modules unless the Tool is safely supported or placed in the tool stand, all energized circuits (e.g. electrical, air, water, etc.) are turned off, pressurized connections are purged and power is discharged from circuits in accordance with the customer's safety practices and policies. Injury or equipment damage can occur with the Tool not placed and energized circuits on. Place the Tool in the tool stand, turn off and discharge all energized circuits, purge all pressurized connections, and verify all circuits are de-energized before performing maintenance or repair(s) on the Tool Changer or modules.



**CAUTION:** Thread locker applied to fasteners must not be used more than once. Fasteners might become loose and cause equipment damage. Always apply new thread locker when reusing fasteners.

### 5.1 Troubleshooting

Refer to the following table for troubleshooting information.

Symptom	Possible Cause	Correction
Air leakage.	Damaged/Worn O-rings/seals/bushings.	Replace O-rings/seals/bushings as needed. Refer to <a href="#">Section 5.2.3—Rubber Bushing Replacement</a> .
	Debris blocking valve seal (for self-sealing valves).	Clean in and around valve components. Ensure fluid stream is free of large particulates; filter as necessary.
	Bent valve piston (for self-sealing valves).	Replace stem. Refer to <a href="#">Section 5.2.1—Master Side Self-Sealing Valve</a> and <a href="#">Section 5.2.2—Tool Side Self-Sealing Valve</a> . Check module attachment to Tool Changer. Refer to <a href="#">Section 2.1—Module Installation</a> . Check robot program and ensure parallel approach trajectory during Tool Changer coupling.
	Corrosion.	Consult ATI Applications Engineering for assistance.
Reduced air flow.	Flow path blockage.	Inspect valve components and supply/return lines for blockage. Clean/repair as necessary.
	Debris blocking valve seal (for self-sealing valves).	Clean in and around valve components. Ensure air stream is free of large particulates; filter as necessary.
Modules unable to couple.	Bent valve piston and/or dowel pin (for self-sealing valves).	Replace the stem. Refer to <a href="#">Section 5.2.1—Master Side Self-Sealing Valve</a> and <a href="#">Section 5.2.2—Tool Side Self-Sealing Valve</a> . Check module attachment to Tool Changer. Refer to <a href="#">Section 2.1—Module Installation</a> . Check robot program and ensure parallel approach trajectory during Tool Changer coupling.

## 5.2 Service Procedures

The following service procedures provide instructions for replacement of components.

### 5.2.1 Master Side Self-Sealing Valve

**Parts required:** Refer to *Section 8—Drawings*

**Tools required:** 2.5 mm Allen Wrench, torque wrench


**Supplies required:** Clean rag, Magnalube G lubricant

1. Place the Tool in a secure location.
2. Uncouple the Master and Tool plates.
3. Turn off and de-energize all energized circuits (e.g. electrical, air, water, etc.).

**NOTICE:** Debris can be expelled at high velocity during the purge, take all required safety precautions.

4. Purge and disconnect all customer plumbing connections to the module.
  - a. Turn the supply lines off.
  - b. Cover the valves with a rag for safety.
  - c. Manually actuate the module's self-sealing valves to purge the line pressure. Note: Debris can be expelled at high velocity during the purge, take all required safety precautions.
5. Depending on the type of service or repair, connections to the module might also need to be disconnected.
6. Remove the valve stem using a 2.5 mm Allen wrench. Do not strip the hex on the valve stem during removal.
7. Remove the check valve piston and spring. Clean any lubrication from the check valve piston, valve stem, spring, and bore in the module housing using a clean rag.
8. Inspect the valve stem for straightness, and replace, if bent.
9. Inspect the o-rings and u-cup seal on the valve stem and check valve piston for wear and damage. Replace components that are damaged or worn.
10. Inspect the spring in the assembly and replace if damaged or worn.

**Figure 5.1—Master Self-Sealing Valve**



11. Lubricate the bore in the module housing with Magnalube G (Teflon/Petroleum based grease).

**NOTICE:** Do not lubricate the O-ring face seal until after installation. Lubricating the O-ring before installation can cause the O-ring to blow out during coupling and uncoupling.

12. If replacing seals, lubricate the valve stem O-ring and the check valve piston U-cup seal with Magnalube G (Teflon/Petroleum based grease).

13. Install the O-ring on the valve stem.


14. Install the U-cup seal on the check valve. Do not get lubrication in the face seal groove in the check valve.

15. Install the non-lubricated O-ring (face seal) into the check valve.

16. Install the spring into the bore in the module housing, seat the check valve on the spring.

17. If the threaded end of the valve stem does not have pre-applied adhesive, apply Loctite 7649 primer and then Loctite 222 or similar thread locker to the threaded end of the valve stem. If the module housing is stainless steel, also add Loctite 7649 primer to the housing threads.

**Figure 5.2—Master Self-Sealing Valve Installation**



18. Install the valve stem. The check valve piston must be pushed down flush with the mating surface of the Master housing in order to install the threaded end of the valve stem. Do not damage the U-cup seal around the check valve piston. A small, flat-head screwdriver can be used to ensure that the U-cup seal is fully located in the recess and not folded over itself prior to screwing in the valve stem. Tighten the stem to 10 in-lbs (1.1 Nm).

19. Lubricate the installed O-ring (face seal) with Magnalube G (Teflon/Petroleum based grease).

20. After the procedure is complete, resume normal operation.

## 5.2.2 Tool Side Self-Sealing Valve

**Parts required:** Refer to [Section 8—Drawings](#)

**Tools required:** 10 mm Allen wrench, Torque wrench

**Supplies required:** Clean rag, Magnalube G lubricant

1. Place the Tool in a secure location.
2. Uncouple the Master and Tool plates.
3. Turn off and de-energize all energized circuits (e.g. electrical, air, water, etc.).


**NOTICE:** Debris can be expelled at high velocity during the purge, take all required safety precautions.

4. All customer plumbing connections to the module must be purged.
  - a. Verify that the supply lines are turned off.
  - b. Cover the valves with a rag for safety.
  - c. Manually actuate the self-sealing valves to purge the line pressure.
5. If required disconnect connections to the module.

**NOTICE:** You might need to remove the Tool side module to access the plug.

6. Remove the plug assembly from the bottom of the air module using a 10 mm Allen wrench.
7. Remove the spring and valve assembly from the housing.


**Figure 5.3—Tool Self-Sealing Valve (Disassembly)**



8. Clean all lubrication from the plug assembly, valve assembly, spring, and bore in the housing using a clean rag.
9. Inspect the dowel pin that is contained in the plug assembly for straightness. Replace the plug assembly if the dowel pin is bent.
10. Inspect the O-rings on the plug and valve assemblies, replace if worn or damaged.
11. Inspect the spring in the assembly and replace if worn or damaged.

12. If replacing the O-rings, lubricate both new O-rings with Magnalube G (Teflon/Petroleum based grease).
13. Install the O-rings on the plug assembly and the valve assembly.

**Figure 5.4—Tool Self-Sealing Valve (Assembly)**



14. Install the check valve piston, make sure it is seated properly in the housing.
15. Install the spring into the housing, make sure it is installed over the step on the check valve.



**CAUTION:** Do not use excess force when installing the plug assembly into the housing. Using excessive force can damage the O-ring and strip the threads on the plug assembly. Thread the plug assembly into the Tool housing by hand, until several threads are engaged into the housing. Then use a 10 mm Allen wrench to complete the installation. Torque the plug to 30 in-lbs (3.39 Nm).

16. Carefully install the plug assembly aligning the dowel pin into the check valve piston. Thread the plug assembly into the housing by hand until several threads are engaged in the housing.
17. Tighten the plug assembly using a 10 mm Allen wrench to 30 in-lbs. (3.39 Nm).
18. Verify the check valve piston is seated properly in the housing.
19. After the procedure is complete, resume normal operation.

### 5.2.3 Rubber Bushing Replacement

**Parts required:** Refer to [Section 8—Drawings](#)


**Tools required:** Needle-nose pliers

**Supplies required:** P80 lubricant

Rubber bushings seal the ports in the Master and Tool plates. If the bushings are damaged, replace them.

1. Place the Tool in a secure location.
2. Uncouple the Master and Tool plates.
3. Turn off and de-energize all energized circuits (e.g. electrical, air, water, etc.).
4. Remove the bushing and collar.
  - a. Use needle-nose pliers to remove the bushing from the module housing.
  - b. If the collar remains in the module housing or inside the bushing, remove the collar.
5. Install the replacement bushing.
  - a. Apply a thin coat of P80 lubricant to the outer surface of the replacement bushing.
  - b. Insert the beveled (chamfered) end of the bushing into the port.
  - c. Insert the collar into the bushing.
  - d. Seat the bushing completely in the bore.
6. After the procedure is complete, resume normal operation.

**Figure 5.5 —Replacing the Bushing and Collar**



## 6. Recommended Spare Parts

Refer to [Section 8—Drawings](#).

Table 6.1—Master module Mounting Fasteners	
Part Number	Description
3500-1066020-21A	M6 x 20 Socket Head Cap Screw, SS, ND Microspheres, 0-3 uncoated lead thds. 5-7 coated thds. IFI525

Table 6.2—Tool module Mounting Fasteners	
Part Number	Description
3500-1066016-21A	M6 x 16 Socket Head Cap Screw, DIN 912 A4 S/S (316) ND Ind. Microspheres Epoxy, Yellow. 0-3 uncoated lead thds. 5-7 coated thds.

Table 6.3—Accessories	
Part Number	Description
3690-0000064-60	Brush, Blue Nylon All Purpose (Cleaning)

## 7. Specifications

<b>Table 7.1—AN5 Master Module Specifications</b>	
<b>9121-AN5-M</b>	Pneumatic Master Module, (6) G3/8 self-sealing ports and (4) G1/2 pass-through ports
<b>Materials of Construction</b>	Anodized aluminum housing and stainless steel valve components, Nitrile seals
<b>Weight:</b>	3.9 lbs (1.77 kg)
<b>Pass-through Ports:</b>	
<b>Quantity</b>	4
<b>Air Pressure</b>	Maximum pressure of 100 psi (6.9 bar)
<b>Cv, Min</b>	4.0
<b>Customer Port Connection</b>	G 1/2 (BSPP)
<b>Self-sealing Valves:</b>	
<b>Quantity</b>	6
<b>Air Pressure</b>	Maximum pressure of 100 psi (6.9 bar)
<b>Cv, Min</b>	1.6
<b>Customer Port Connection</b>	G 3/8 (BSPP)

<b>Table 7.2—AN5 Tool Module Specifications</b>	
<b>9121-AN5-T</b>	Pneumatic module with (6) G3/8 self-sealing ports and (4) G1/2 pass-through ports - Tool
<b>Materials of Construction</b>	Anodized aluminum housing and stainless steel valve components, Nitrile seals, PVC port plug
<b>Weight:</b>	2.8 lbs (1.27 kg)
<b>Pass-through Ports:</b>	
<b>Quantity</b>	4
<b>Air Pressure</b>	Maximum pressure of 100 psi (6.9 bar)
<b>Cv, Min</b>	4.0
<b>Customer Port Connection</b>	G 1/2 (BSPP)
<b>Self-sealing Valves:</b>	
<b>Quantity</b>	6
<b>Air Pressure</b>	Maximum pressure of 100 psi (6.9 bar)
<b>Cv, Min</b>	1.6
<b>Customer Port Connection</b>	G 3/8 (BSPP)

## 8. Drawings

REV. 01	DESCRIPTION Initial Drawing	INITIATOR M/JG	DATE 6/28/2018
------------	--------------------------------	-------------------	-------------------

**Notes:**

- Materials of Construction
  - Housings - Anodized Aluminum
  - Valve Components - Stainless Steel, Nitrile and PVC
  - Replacement stem contains pre-applied thread locker. Use Loctite 7649 primer and Loctite 222 if reassembling with original stem.
- Operation:
  - For best results keep air module mating surfaces free and clear of any debris.
  - Checked ports can produce significant forces when under high supply pressures. These forces have to be overcome to achieve tool changer coupling.
  - Checked ports do not support vacuum conditions.
  - The modules have (6) G 3/8 (BSPP) checked ports and (4) G 1/2 (BSPP) Pass-thru ports for air or vacuum service.

ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	6	3410-0001067-01	O-ring, 10mm x 2mm, Buna N, Dur. 90
2	6	3410-0001284-01	O-ring, .669OD x .047 wall, 70D, Buna-N
3	6	3700-20-1457	SW-150A Tool Check Valve Piston
4	6	3700-20-1460	SPRING, F/A TOOL
5	6	3700-20-4121	Fluid/Air Long Plug for QC-210/310 Tool

ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	6	3410-0001065-01	O-Ring 14MM X 2MM Buna
2	6	3410-0001068-01	Mini U-Cup Seal 18mm ID x 22mm Buna
3	6	3410-0001183-01	O-Ring 6MM X 2MM Buna D90
4	6	3700-20-1459	SW-150A Master Fluid / Air Spring SS
5	6	3700-20-2994	Master Check Valve Piston, FA44
6	6	3700-20-2996	VALVE STEM, HIGH STRENGTH
7	4	3700-20-4748	Collar for 1/2" Bushing
8	4	4010-0000063-01	1/2" Rubber Bushing, Nitrile

Note: Service Kit 9120-F1-T-Kit consists of (1) each of items 1, 2, & 4.  
 Note: Service Kit 9120-F5-T-Kit consists of (1) each of items 1 thru 5.

**Notes:** UNLESS OTHERWISE SPECIFIED, ALL DIMENSIONS ARE IN MILLIMETERS.

DO NOT SCALE DRAWING. ALL DIMENSIONS ARE IN MILLIMETERS.

PROPERTY OF AT INDUSTRIAL AUTOMATION, INC. NOT TO BE REPRODUCED IN ANY MANNER EXCEPT ON ORDER OR WITH PRIOR WRITTEN AUTHORIZATION OF AII.

1031 Goodworth Drive, Apex, NC 27539, USA  
 Tel: +1 919.772.0115  
 Fax: +1 919.772.8259  
 www.ati-ia.com  
 ISO 9001 Registered Company