


Rev.	Description	Initiator	Date
03	ECO 19300: Battery Enclosure Cable Connector: Updated Part Number.	TBC	10/1/2020



Note Connector Orientation

**MiniFast 5-Pin M12 Connector Pinout**

Pin No.	Wire Color	Voltage
1	Brown (N/C)	N/A
2	White	0
3	Blue	+6V
4	Black (N/C)	N/A
5	Gray (N/C)	N/A

Battery Enclosure Cable Connector  
Turck 5-Pin Male M12 MiniFast  
EFSBQ-A5.500.2-0.5  
Face Side  
Scale 2 : 1





Table 1

Battery Box Part Number	Battery Box Description	Cable Part Number	Cable Description
9005-20-2374	CEM Servo Backup Battery Assembly, 5-Pin Male M12 Connector	9120-C-5EM-5EF-XXX	Turck EuroFast 5-Conductor Extension Cable

- Notes:
- Battery enclosure is diecast aluminum with black powder paint.
  - Weight given is for enclosure with batteries and 1 meter cable.
  - Battery enclosure to be mounted on customer tooling in convenient location.
  - Battery enclosure cover includes a seal for water resistance and a label for recording battery installation date. (Customer to supply batteries).
  - Battery life is dependent on the amount of time the customer's tooling is coupled to the ATI master module and in production. Long periods without use shorten battery life. When tooling is idle, replace batteries at least every three months. When tooling is in frequent use, replace batteries at least once annually.

NOTES: UNLESS OTHERWISE SPECIFIED.

DO NOT SCALE DRAWING. ALL DIMENSIONS ARE IN MILLIMETERS.

1031 Goodworth Drive, Apex, NC 27539, USA  
Tel: +1.919.772.0115 www.ati-ia.com  
Fax: +1.919.772.8259 ISO 9001 Registered Company

PROPERTY OF ATI INDUSTRIAL AUTOMATION, INC. NOT TO BE REPRODUCED IN ANY MANNER EXCEPT ON ORDER OR WITH PRIOR WRITTEN AUTHORIZATION OF ATI.

DRAWN BY: R.Robinson 7/14/18  
CHECKED BY: W. Berrocal, 7/24/18

PROJECT # SHEET 1 OF 1

TITLE: Servo Remote Battery Backup Module w/EuroFast Cable

SCALE	SIZE	DRAWING NUMBER	REVISION
1:2	B	9630-20-BATTERY BACKUP-5-PIN	03